


CORNING

Installation Instructions

Issue 3, Dec 2021

BPEO TRAY HD 1 slot 2x12 fusions Ø 2,4x40 or 45 mm for G657 fibers


These installation instructions are provided as guidance for the trained craftsperson carrying out the installation




Contents

1.	Recommended tools	1
2.	Routing of the fibre inside the tray	2
3.	Place the fusion splices staggered	3
4.	Identification of the tray	3
5.	Assembly the tray on the organiser	4
6.	Dissassembly the tray on the organiser	5
7.	Cover use	6

1. Recommended tools




2. Routing of the fibre inside the tray




3. Place the fusion splices staggered


Splice tray accept heat shrink fusion splice protectors of 2.4 diameter x 40 or 45 mm (dim. after shrinkage)






4. Identification of the tray




5. Assembly of the tray on the organiser



6. Dissassembly of the tray from the organiser



7. Cover use



Corning Optical Communications GmbH & Co. KG • Leipziger Strasse 121 • 10117 Berlin, GERMANY

+00 800 2676 4641 • FAX: +49 30 5303 2335 • www.corning.com/opcomm/emea

Corning Optical Communications reserves the right to improve, enhance, and modify the features and specifications of Corning Optical Communications products without prior notification. A complete listing of the trademarks of Corning Optical Communications is available at www.corning.com/opcomm/trademarks. All other trademarks are the properties of their respective owners. Corning Optical Communications is ISO 9001 certified. © 2019 Corning Optical Communications.

All rights reserved. N962024X/ Dec 2021